

# laservision

## laser protection Roll-Up BC3.F1P01.1RU1



Article number: BC3F1P011RU1  
GTIN: 4050369018297  
Unit: piece  
Weight incl. packaging: 4,05 kg  
Weight excl. packaging: 4,00 kg

### Highlights

The Roll-up is characterized by a unique flexibility combined with high stability. The laser safety Roll-up consists of a single layer version of the laser safety curtain SHELTER-LIGHT. The lightweight module is hold in place by two metal profiles and put upright by means of special metal expanding systems. Together with interconnecting elements several segments can be combined to a large laser safety wall.

<b>COLOUR:</b>	silver grey
<b>PROPERTIES:</b>	Lightweight single-sided usable
<b>PROTECTION RANGE:</b>	Infrared near infrared ultraviolet visible
<b>PROTECTION CLASS / NORM:</b>	EN 12254

WAVELENGTH	OD	OPERATING MODE / TESTED PROTECTION LEVEL
180 - 315	(OD5+)	180-315 D AB5 + IR AB3 + M AB5Y
>315 - 1050	(OD5+)	>315-1050 DIRM AB5
>1050 - 1400	(OD5+)	>1050-1400 DIRM AB5
>1400 - 20000	(OD3+)	>1400-20000 DI AB3 + R AB3Y + M AB4