

E25.M7P06.1001 (E25 basic module)



Article number: E25M7P061001
GTIN: 4050369052161
Unit: piece
Weight incl. packaging: 27,40 kg
Weight excl. packaging: 27,40 kg

Highlights

The E25 basic module E25.M7P06.1001 is formed by an E25 start and end module of the modular laser protection folding wall system from laservision. a completely assembled laser protection wall with the dimensions 2100x1257x308mm (HBT per module). Depending on the application, this can be expanded by up to 7 additional intermediate modules (E25.M7P06.1002). The ready-to-use basic module is filled with the plate material M7P06 as standard, which is based on a special aluminum sandwich structure with coated aluminum cover plates (black). The partition can e.g. can be set up as a room divider in laboratories or as a laser-safe partition around optical tables.

COLOUR:	black
PROTECTION RANGE:	Infrared near infrared
PROTECTION CLASS / NORM:	EN 12254 EN 60825-4
PROPERTIES:	both-sides usable freely selectable number of modules proven hinge system stable standing standard plate material M7P06