

high speed scanning in pocket size

SCANLAB's *SCAN*cube series of **scan heads** are characterized by their remarkably compact construction. These **2D scan systems** enable deflecting and positioning of laser beams in the working plane.

Key Features

- Compact & lightweight design
- Robust, sealed housing
- High dynamic performance
- Large selection of mirror coatings

In addition to its robust housing, the *SCAN*cube series offers an attractive price/performance ratio, making it the best choice for your standard applications.

Typical Applications

- Marking tasks
- Semiconductor-industry materials processing
- Microstructuring
- Processing-on-the-fly





Features of the SCANcube und SCANcube III Product Lines

Summary

The SCANcube product line is optimized for the demands of typical marking applications.

SCANcube III scan heads address marking tasks that prioritize faster write speeds and far higher precision, along with long-term stability.

Shared Characteristics

- Full electrical compatibility
- Full mechanical compatibility
- Design optimized for labeling and marking in industrial environments

SCANcube III Performance Enhancements

Boosts in:

- Scan speed: up to 100%
- Dynamic performance: up to 50%

Reductions in:

- Long-term drift: more than 50%
- Temperature drift: more than 40%
- Heat generation: more than 50%

Options & Variants

Extensions

- varioSCAN: Extension into a 3-axis scan system
- Camera adapter: Optical process monitoring

Mirrors

- Over 40 standard coatings for various wavelengths
- Maximum average powers up to 250 W for standard systems

Objectives

- Standard range of over 330 objectives available for the SCANcube series from leading manufacturers to achieve various image fields and focal lengths
- Matching mechanical objective mount on scan head, optimized to take occurring back reflections into account
- Objective-specific correction files

Control boards

• RTC4 (PCIe, Ethernet) or RTC5

Software

- laserDESK: Professional software for laser marking and laser processing of materials
- correXion pro: System-specific customizing of correction files



Laser Engraving





Marking

Day & Night Design



Specifications

Dynamics

	SCANcube 7	SCANcube 8.5	SCANcube 1	10	SCAN cube	14
Product line	I-series	I-series	I-series	III-series	I-series	III-series
Aperture [mm]	7	8.5	10	10	14	14
Tracking error [ms]	0.14	0.14	0.16	0.12	0.30	0.15
Typical speeds (1)						
Marking speed [m/s]	2.5	2.5	2.0	3.0	1.0	2.0
Positioning speed [m/s]	15.0	15.0	10.0	16.0	7.0	14.0
Writing speed [cps] (2)						
good writing quality [cps]	900	900	640	925	410	740
high writing quality [cps]	600	600	400	500	280	320
Step response time (3)						
1 % of full scale [ms]	0.25	0.30	0.40	0.30	0.65	0.35
10% of full scale [ms]	0.70	0.70	1.2	0.80	1.6	0.90

 $^{(1)}$ with F-Theta objective, f = 160 mm

(2) single-stroke characters of 1 mm height

(3) settling to 1/1000 of full scale

Precision & Stability

	SCAN cube	SCANcube III
Repeatability (RMS) [µrad]	< 2	< 2
Positioning resolution [bit] (4)	16	16
Nonlinearity	< 3.5 mrad/44°	< 0.9 mrad / 44°
Temperature drift		
Offset [µrad/K]	< 30	< 25
Gain [ppm/K]	< 80	< 25
Long-term drift		
8-h-drift (after 30 min warm-up) (5)	< 0.3 mrad ⁽⁶⁾	
Offset [µrad]		< 100
Gain [ppm]		< 100

 $^{\scriptscriptstyle (4)}$ based on the full angle range (e.g. positioning resolution 11 µrad for angle range ±0,36 rad)

⁽⁵⁾ at constant ambient temperature and load
⁽⁶⁾ plus temperature-includet Gain and Offset drift

plus temperature melader cum and onser a

Common Specifications

	SCANcube Serie	
Optical performance		
Typical scan angle [rad]	±0.35	
Gain error [mrad]	< 5	
Zero offset [mrad]	< 5	
Power requirements	±15 V DC,	
	max. 3 A each	
Interface		
digital version	SL2-100 or XY2-100	
analog version	±4.8 V	
IP protection class	IP 50 ⁽⁷⁾	
Operating temperature [°C]	25 ± 10	

(all angles are in optical degrees)

⁽⁷⁾ also available as IP 66 for SCANcube III 10 and 14 on request

06/2019 Information is subject to change without notice. Product photos are non-binding and may show customized features. Application pictures: iStock.com/JAIcaraz, iStock.com/scanall, iStock.com/bernie_photo



Google Play A



SCANLAB GmbH · Siemensstr. 2a · 82178 Puchheim · Germany Tel. +49 (89) 800 746-0 · Fax +49 (89) 800 746-199 info@scanlab.de · www.scanlab.de SCANLAB America, Inc. · 100 Illinois St · St. Charles, IL 60174 · USA Tel. +1 (630) 797-2044 · Fax +1 (630) 797-2001 info@scanlab-america.com · www.scanlab-america.com

