

Two Axis Tilt Stages | AIS

RoHS



Tilt stages for adjusting the tilt of a sample on the table top to an arbitrary angle. The adjustment knobs are located on the side of the stage to minimize protrusions.





- The adjustment knob style is ideal for quick and easy tilt adjustment.
- The micrometer style is effective in confined spaces where vertical control from the top is required.

Attention

- Please use in surface load because the three-point support structure. It can not be used hanging on the wall or upside down.

**Outline Drawing****AIS-25B** Pan head screw M2x6...2 screws, Flat washers**AIS-40B/40BUU** Pan head screw M3x6...2 screws, Flat washers Hexagonal socket head cap screw 6-32UNCx1/4...2 screws (UU)

Part Number	A (mm)	B (mm)	C	D	E
AIS-40B	16	32	M3	M6 P1	M6 P1
AIS-40BUU	15.875	31.75	6-32UNC	1/4-20UNC	8-32UNC

AIS-60B Hexagonal socket head cap screw M4x8...2 screws**AIS-65B-M6/65BUU** Hexagonal socket head cap screw M6x6...2 screws (M6) Hexagonal socket head cap screw 1/4-20UNCx1/4...2 screws (UU)

Part Number	A (mm)	B	C
AIS-65B-M6	25	M6 P1	M4
AIS-65BUU	25.4	1/4-20UNC	8-32UNC

Specifications

Part Number	METRIC	AIS-25B	AIS-40B	AIS-60B	AIS-65B-M6
	INCH	—	AIS-40BUU	—	AIS-65BUU
Stage Size [mm]		25×25	40×40	60×60	65×65
Tilt Range [°]		±2	±2	±2	±2
Travel per Knob Rotation [°]		about 1.8	about 1	about 0.65	about 0.58
Primary Material		Aluminum			
Finish		Black anodized			
Load Capacity [N]		9.8 (1.0kgf)	29.4 (3.0kgf)	49.0 (5.0kgf)	49.0 (5.0kgf)
Weight [kg]		0.04	0.06	0.17	0.2

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

Motorized Stages

Light Sources & Laser Safety

Index

Guide

X Axis Stages

XY Axis Stages

Z Axis Stages

XZ Axis Stages

XYZ Axis Stages

Rotation Stages

Goniometer

Tilt Stages

Vacuum

Ball Bearing Guide

Crossed Roller

Dovetail

Lapping

V Groove Screw

Others

15 × 15 mm

25 × 25 mm

40 × 40 mm

60 × 60 mm

65 × 65 mm

80 × 80 mm

100 × 100 mm

120 × 120 mm

Others




Guide

▶ Since the Stage Sizes of AIS-8013B/1016B/1622B are the same as that of the precision labjacks (LJ/LJA), these can be used in combination with the labjacks. [Reference](#) E114 [Catalog Code](#) W7055




Outline Drawing


AIS-100B Hexagonal socket head cap screw M4×10...4 screws, Spring washers




AIS-100CM Hexagonal socket head cap screw M4×12...4 screws, Spring washers




AIS-8013B Hexagonal socket head cap screw M4×16...4 screws



AIS-1016B Hexagonal socket head cap screw M4×16...4 screws



AIS-1622B Hexagonal socket head cap screw M4×16...4 screws



Specifications

Part Number	METRIC	AIS-100B	AIS-100CM	AIS-8013B	AIS-1016B	AIS-1622B
Stage Size [mm]		100×100	100×100	80×130	100×160	160×220
Tilt Range [°]	α axis (Narrow side direction)	±2	±3	±1.4	±1.2	±0.7
	β axis (Long side direction)	±2	±3	±0.8	±0.7	±0.6
Travel per Knob Rotation [°]	α axis (Narrow side direction)	about 0.36	about 0.35	about 0.74	about 0.6	about 0.33
	β axis (Long side direction)	about 0.36	about 0.35	about 0.37	about 0.32	about 0.22
Primary Material		Aluminum				
Finish		Black anodized				
Load Capacity [N]		68.6 (7.0kgf)	68.6 (7.0kgf)	78.4 (8.0kgf)	98.0 (10.0kgf)	98.0 (10.0kgf)
Weight [kg]		0.51	0.6	0.8	1.2	2.5

Application Systems

Optics & Optical Coatings

Opto-Mechanics

Bases

Manual Stages

Actuators & Adjusters

MotORIZED Stages

Light Sources & Laser Safety

Index

Guide

X Axis Stages

XY Axis Stages

Z Axis Stages

XZ Axis Stages

XYZ Axis Stages

Rotation Stages

Goniometer

Tilt Stages

Vacuum

Ball Bearing Guide

Crossed Roller

Dovetail

Lapping

V Groove Screw

Others

15 × 15 mm

25 × 25 mm

40 × 40 mm

60 × 60 mm

65 × 65 mm

80 × 80 mm

100 × 100 mm

120 × 120 mm

Others